

Light Source	3 white & 3 red ultrabright LED	
Light Output (lumens)	30	Red flash
Running Time	2hrs	7h30
Battery	Li-Polymer rechargeable 180mAh 3.7V	
Product Dimensions	(L) 51.9 x (W) 42.2 x (H) 21.1 mm	
Product Weight	21 g (including battery)	
NS Part No	NSENDURASTAR	
Supplied with	Bike stand, Arm band, Micro USB cable	



Mode operation - Product information - Warning

Operation

- Press the ON/OFF switch to turn on your EnduraStar on low power (FRONT WHITE LIGHT)
- Press again for the full power (FRONT WHITE LIGHT)
- Press a third time for the REAR STEADY RED LIGHT
- Press a fourth time for the REAR FLASHING RED LIGHT
- Press a fifth time for both REAR FLASHING RED LIGHT and the FRONT WHITE LIGHT ON FULL POWER
- Press again to turn OFF the light

Battery Installation & replacement

- Remove the USB cover
- Use the supplied USB lead and connect both end to the torch and the mains supply (USB output: computer, laptop)
- Red light: still in charge // Off the light: charging process complete

Warning

- Do not flash the light beam directly to people's eyes

Utilisation - Information produit - Avertissement

Mode de fonctionnement

- Appuyer sur l'interrupteur ON/OFF pour la lumière blanche sur la faible intensité (lumière blanche frontale)
- Appuyer une seconde fois pour la lumière blanche haute intensité (lumière blanche frontale)
- Appuyer une troisième fois pour activer la lumière rouge arrière (constant)
- Appuyer une quatrième fois pour activer la lumière rouge arrière (clignotant)
- Appuyer une cinquième fois pour activer la lumière rouge arrière (clignotant) et la lumière blanche frontale haute intensité
- Appuyer une dernière fois pour éteindre votre lampe.

Installation des batteries

- Retirer le capuchon de prise Usb (USB cover)
- Utiliser le câble USB fourni et connecter à la fois la fin de la torche et l'alimentation secteur.
- Lumière rouge: toujours en charge // Indicateur LED éteint: le processus de charge est terminé.

Maintenance

- Ne regardez pas directement la LED. Cela peut endommager la vue.
- NE PAS exposer la batterie au feu / températures élevées ou à des conditions de froid / humide extrêmes.

GUARANTEE TERMS

NightSearcher products have been carefully tested and inspected before shipment and are guaranteed to be free from defective materials and workmanship for a period of 12 months (battery not covered) from the date of purchase, provided that the enclosed instructions have been followed. Should you experience problems with your NightSearcher product, please return the item, complete with any chargers, to your place of purchase or contact NightSearcher Ltd direct. Your NightSearcher guarantee does not apply to consumables (LEDs and battery), normal wear and tear, nor does it cover any damage caused by misuse, careless or unsafe handling, alterations, accidents or repairs attempted or made by any personnel without prior approval from NightSearcher Ltd. Your NightSearcher guarantee is not effective unless you can provide a dated proof of purchase. Please note that this guarantee does not affect your statutory rights. If at any time, you need to dispose of this product or parts of this product: Please note that waste electrical products, batteries and bulbs should not be disposed of with household waste. Please recycle where facilities exist, check with your local authority for recycling advice.

NIGHTSEARCHER LIMITED - Unit 4 Applied House - Fitzherbert Spur – Farlington – Portsmouth – PO6 1TT – UNITED-KINGDOM

Visit our website on www.nightsearcher.com